




INTERSYS VMS SYSTEM MONITOR QUICK GUIDE

INTRODUCTION

The System Monitor is a light weight application for monitoring the status of the Intersys VMS surveillance system.

For information on installing System Monitor or other client applications, please refer to Intersys VMS Installation Guide.

For information on using Workstation or System Manager, please refer to Intersys VMS Administrator's Guide.

The guides are on the www.nuvico.com. You can also access the Administrator's Guide by clicking Help in System Manager. You can access the User's Guide by clicking Help in Workstation.


IMPORTANT: SYSTEM MONITOR DISABLED IN 7.0

It is important to note that System Monitor has been temporarily disabled in Intersys VMS 7.0. It will be reinstated in future maintenance releases.

STARTING SYSTEM MONITOR

To start the application, double-click the System Monitor icon on the Windows desktop.


After the "Select address" tool has loaded, select the Master recorder to which to connect. In most cases, you can just wait for 10 seconds, and the tool automatically connects to the default Master recorder.



After selecting the Master recorder, the login screen appears.


Type your user name and password, and optionally mark the "Remember password" checkbox to speed up your next login.

After filling in your login details, click "Login".



After logging in, the System Monitor opens into the notification area, presenting the status of the surveillance system automatically.

The automatic notification will fade after a short interval.



After that, the system status can be viewed by placing the cursor over the system monitor notification icon.

The full functionality of the tool can be accessed by right clicking on the System Monitor notification icon and selecting “Show Status”.


SYSTEM MONITOR - FULL MODE

Once opened from the notification area, System Monitor opens in a non-detailed mode:



The non-detailed mode lists the number of errors, warnings, unknown statuses and fully functional components for the system and each recorder.

For further information on the status of the system and recorders, you can access the detailed mode by clicking on “Details”:



EXPORTING LOGS

In case log export is required due to technical support needs, click “Log export” and set the location and name of the log file.

The logs are saved in ZIP format.

SETTINGS

You can set automatic login details by clicking on “Settings”:

